PERIFLEX[®] elastic couplina

Replacement tyre

- Tyre for PERIFLEX® coupling

- Replace the tyre without dismantlina the machine
- Material natural rubber Tyre R (NR) equipped with disposed material in R
- Quality tyre X(1) with inserts mounted in X nattern

Assembly

ΡΝΑ

- The elastic coupling is delivered pre-assembled. To mount the coupling, remove the tyre and place the hubs and locking assemblies on their respective shafts. Bring the two assemblies together respecting the distance "O" and aligning the two hubs with a straight edge or template.
- Place the tyre between the two hubs ensuring there is minimum radial backlash (2-15mm depending on the size of the coupling). Then bring the two locking assemblies together, tightening pairs of diametrically opposite screws to the prescribed toraue. As the rubber may decompress with time, re-check the torque after a few hours.



SAVE MONEY ! Only change the tyre DISCOUNTS

Qty.	1+	5+	10+
Disc.	List	-3%	On request

Part number spare tyre	for PERIFLEX® coupling part number	Type of tyre	Stock*	Price each 1 to 4
203R	PNA2-203	R	 ✓ 	86,27 €
206R	PNA6-206	R	 ✓ 	105,43 €
210R	PNA16-210	R	 ✓ 	159,10 €
214R	PNA40-214	R	 ✓ 	247,29 €
218R	PNA63-218	R	 ✓ 	256,88 €
414X	PNA40-214	Х	-	249,22 €
418X	PNA63-218	Х	-	274,13 €

*Depending on availability - Dimensions in mm



